



# GSM gate controller GV17

## Installation manual

(FW:2.03)

December, 2020



# Contents

<b>SAFETY PRECAUTIONS.....</b>	<b>3</b>
<b>1 DESCRIPTION.....</b>	<b>4</b>
1.1 SPECIFICATIONS.....	4
1.2 CONTROLLER ELEMENTS.....	5
1.3 PURPOSE OF TERMINALS.....	5
1.4 LED INDICATION OF OPERATION.....	6
1.5 GSM GATE CONTROLLER <i>GV17</i> STANDARD PACKING LIST.....	6
<b>2 WIRING SCHEMATICS FOR THE GSM GATE CONTROLLER <i>GV17</i>.....</b>	<b>7</b>
2.1 FASTENING.....	7
2.2 SCHEMATIC FOR CONNECTING THE POWER SUPPLY.....	7
2.3 SCHEMATICS FOR CONNECTING INPUTS.....	7
2.4 SCHEMATIC FOR CONNECTING THE RELAY.....	8
2.5 SCHEMATIC FOR CONNECTING AN AUTOMATIC GATE OPENER TO THE <i>GV17</i> .....	8
2.6 SCHEMATIC FOR CONNECTING THE W485 WiFi MODULE.....	8
2.7 SCHEMATIC FOR CONNECTING THE E485 “ETHERNET” MODULE.....	9
<b>3 QUICK SET UP OF THE CONTROLLER.....</b>	<b>9</b>
<b>4 REMOTE CONTROL.....</b>	<b>9</b>
4.1 CONTROL WITH PHONE CALL.....	9
4.2 CONTROL WITH PHONE KEYBOARD.....	9
4.3 CONTROL USING <i>PROTEGUS CLOUD</i> .....	10
4.4 ADDING A WIDGET ON YOUR PHONE.....	12
4.5 ADDING USERS ON YOUR PHONE.....	15
4.6 CONTROL WITH SMS MESSAGES.....	17
4.7 CONFIGURATION WITH SMS MESSAGES.....	17
<b>5 SETTING PARAMETERS USING <i>TRIKDISCONFIG</i> SOFTWARE.....</b>	<b>19</b>
5.1 <i>TRIKDISCONFIG</i> STATUS BAR.....	20
5.2 “SYSTEM OPTIONS” WINDOW.....	20
5.3 “IN/OUT” WINDOW.....	21
5.4 “MODULES” WINDOW.....	23
5.5 “IP REPORTING” WINDOW.....	25
5.6 “USER LIST” WINDOW.....	26
5.7 “EVENTS LOG” WINDOW.....	28
5.8 RESTORE DEFAULT SETTINGS.....	28
5.9 SETTINGS FOR GATE STATE INDICATION.....	29
<b>6 SETTING PARAMETERS REMOTELY.....</b>	<b>30</b>
<b>7 TESTING OF GSM GATE CONTROLLER <i>GV17</i>.....</b>	<b>30</b>
<b>8 UPDATING FIRMWARE MANUALLY.....</b>	<b>30</b>



## **Safety precautions**

The GSM gate controller should only be installed and maintained by qualified personnel.

Please read this manual carefully prior to installation in order to avoid mistakes that can lead to malfunction or even damage to the equipment.

Always disconnect the power supply before making any electrical connections.

Any changes, modifications or repairs not authorized by the manufacturer shall render the warranty void.



Please adhere to your local waste sorting regulations and do not dispose of this equipment or its components with other household waste.



# 1 Description

GSM gate controller **GV17** can remotely control automatic gates and other equipment.

Users can control **GV17** with **Protegeus** application, telephone calls and SMS messages. The controller can recognize up to 7 administrator and 990 user telephone numbers. A user control schedule and counter for how many times a specific user can control the system can be set for the **GV17**. The GSM controller can send SMS messages informing when inputs and outputs are activated and restored (the text of the SMS messages is customizable). The controller is capable of sending event messages to the receiver of a security company. Connecting a WiFi (**W485**) or Ethernet (**E485**) module to the **GV17** controller can send event messages and control the controller over a wireless or wired internet without using SIM card mobile data.

## Features

### Remote control

- With Mobile/Internet application **Protegeus**.
- With SMS messages.
- With phone call.

### Messages for users

- Sends messages about events to the **Protegeus** application or with text SMS messages.

### Messages for the safety company

- Sends event information in Contact ID codes to TRIKDIS software and hardware receivers, which work with any monitoring software.
- Can simultaneously send event messages to the receiver of the safety company and work with the **Protegeus** app.
- If connection with the main receiver is lost, the messages are automatically sent to a backup receiver.



### Inputs and outputs

- 2 inputs (IN), of selectable type: NO; NC; EOL.
- 2 universal inputs/outputs. Mode of operation is set as either input or output.
- 1 output (OUT) - relay.

### Settings and installation

- Quick and easy installation.
- Addition of new users and deletion of existing users can be done with the **Protegeus** app (when logged in with administrator rights), SMS message, **TrikdisConfig** software.
- Device can be configured either by connecting a USB Mini-B cable or remotely with the **TrikdisConfig** software.
- Remote updating of firmware.
- Two access levels for configuring the device, for the installer and for the administrator.


## 1.1 Specifications

Parameter	Description
2G GSM modem frequencies	850 / 900 / 1800 / 1900 MHz
3G UMTS modem frequencies	800 / 850 / 900 / 1900 / 2100 MHz
Power supply voltage	9-32 V DC 12-24 V AC
Current consumption	100 mA
Inputs	2, selectable type: NC, NO, EOL=10 kΩ
Universal inputs/outputs	2, can be set either as input IN with type: NC, NO, EOL=10 kΩ, or output OUT (open collector (OC) 50 mA)



Parameter	Description
Output	1, relay, 1 A 30 V DC, 0,5 A 125 V AC
Unsent events memory	Up to 60 events
Event log memory	Up to 5000 events
Users who receive messages and have permission to control	7
Users who have permission to control	990
Operating environment	Temperature from –20 °C to +50 °C, relative humidity – up to 80% at +20 °C
Dimensions	92 x 62 x 26 mm
Weight	80 g

### 1.2 Controller elements



### 1.3 Purpose of terminals

Terminal	Description
AC/+DC	Power terminal (9-32 V DC positive; 12-24 V AC)
AC/-DC	Power terminal (9-32 V DC negative; 12-24 V AC)
1 IN	1 <sup>st</sup> input, of selectable type NO, NC, EOL (factory setting: NO)
2 IN	2 <sup>nd</sup> input, of selectable type NO, NC, EOL (factory setting: NO)
COM	Common terminal
3 I/O	Input/output (factory setting: type OC output)
4 I/O	Input/output (factory setting: type OC output)
NC	Relay terminal NC
C	Relay terminal C
NO	Relay terminal NO
A RS485	Contact A of RS485 bus
B RS485	Contact B of RS485 bus



## 1.4 LED indication of operation

Indicator	Light status	Description
NETWORK	Green solid	Connected to GSM network
	Yellow blinking	Indication of GSM signal strength from 0 to 5. Sufficient strength is 3.
DATA	Green solid	Message is being sent
	Yellow solid	There are unsent event messages in the data buffer
POWER	Green blinking	The power supply voltage is sufficient
	Yellow blinking	The power supply voltage is insufficient
	Red and yellow blinking	Configuration mode is on
TROUBLE	Off	No operation problems
	1 blink	No SIM card inserted
	2 blinks	The PIN code of the SIM card is incorrect
	3 blinks	Unable to connect to GSM network
	4 blinks	Unable to connect to <b>Protegeus</b> or to the primary IP receiver
	5 blinks	Unable to connect to the backup IP receiver
	6 blinks	Internal clock is not set
7 blinks	The power supply voltage is insufficient	

If the LED indication is not working, check the power supply and connections.

**Note:** Before beginning installation, make sure that you have the necessary components:

1. USB Mini-B type cable for configuration.
2. Cable consisting of at least 4 wires for connecting the controller.
3. Flat-head 2,5 mm screwdriver.
4. External GSM antenna if reception is weak in the area.
5. Activated nano-SIM card (can have turn off PIN code requests).
6. Instruction manual for the automatic gate to which the GSM gate controller is about to be connected.

Order the necessary components separately from your local retailer.

## 1.5 GSM gate controller GV17 standard packing list


- GSM gate controller GV17 1 pc.
- GSM antenna 1 pc.
- Resistor 10 k $\Omega$  3 pcs.
- Double-sided adhesive tape (5 cm) 1 pc.
- Screw 2 pcs.



## 2 Wiring schematics for the GSM gate controller GV17


### 2.1 Fastening

1. Remove the top lid. Pull out the plug part of the terminal block.
2. Remove the PCB board.
3. Fasten the base of the case in the desired place using screws.
4. Reinsert the board and the terminal block.
5. Screw the GSM antenna in.
6. Insert the nano-SIM card.
7. Close the top lid.



### 2.2 Schematic for connecting the power supply


Using wires, connect the **GV17** controller according to the schematic shown below.




### 2.3 Schematics for connecting inputs

The **GV17** has four inputs IN (two of which are universal and can operate either as inputs or outputs) for the connection of various alarm sensors. These inputs can operate in NC, NO, EOL modes. Connect the inputs according to the set input type (NC, NO, EOL) as is shown in the schematics below:


Normally open (NO).  
Short - Alarm; Open - Restore.




Normally closed (NC).  
Short - Restore; Open - Alarm.



Normally closed with 10k End of line resistor (EOL). Short - Alarm; Open - Alarm; 10k - Restore.




Normally open with 10k End of line resistor (EOL). Short - Alarm; Open - Alarm; 10k - Restore.





### 2.4 Schematic for connecting the relay

Above is the schematic for connecting the relay when the **GV17** is connected to a DC power source. Using the terminals of the relay, it is possible to remotely control (turn on/off) various electric devices. The I/O terminal of the controller must be set to an output (OUT) mode.




### 2.5 Schematic for connecting an automatic gate opener to the GV17

All wiring should be done with the power supply disconnected.

The purposes and voltages of the automatic gate opener’s terminals are described in detail in the automatic gate’s manual.

The automatic gate’s IN, COM terminals are used for controlling the gates.

The automatic gate has a gate state output (OUT) that shows when the gates are closed and when they are open. The gate’s state output can be a voltage output or a relay output. In the schematic, relay K1 is connected to a voltage automated gate output. There is voltage (~230V) between the voltage outputs OUT and N of the automated gates when the gates are open. The intermediate relay K1 is turned on when the gates are open and it activates the **GV17**’s 1IN input.



The state of the **GV17**’s 1IN input gives precise information about the state of the gates (when the gates are closed and when they are open). Configuring the **GV17** with the gate state indication is described in chapter 5.9 “Settings for gate state indication”.


### 2.6 Schematic for connecting the W485 WiFi module

**GV17** firmware version from 1.06.

The **W485** module sends messages to the CMS (Central Monitoring Station) and to **Protegeus** using a WiFi internet router. When WiFi connectivity is available, the **GV17** sends event messages via the **W485** module. When WiFi connectivity is disrupted, the **GV17** sends messages via GPRS. When WiFi connectivity is re-established, the **GV17** returns to sending messages via **W485**.

Configuration of the **W485** WiFi module to work with the **GV17** is described in chapter 5.4. „„Modules” window”.

**You do not need a SIM card, when using the W485 with the GV17.**








## 2.7 Schematic for connecting the E485 “Ethernet” module

GV17 firmware version from 1.06 .

The **E485** sends messages to the CMS (Central Monitoring Station) and to **Protegeus** using a wired internet connection. Using the **E485** with **GV17**, CMS and **Protegeus** messages are sent over wired Internet and mobile Internet is not used. If a wired internet connectivity is disrupted, the **GV17** sends messages via the mobile Internet. When the wired Internet connectivity is re-established, **GV17** starts sending messages via **E485**.

Configuration of the **E485** module to work with the **GV17** is described in chapter 5.4. „Modules” window”.

**You do not need a SIM card, when using the E485 with the GV17.**



## 3 Quick set up of the controller

**Note:** The controller comes factory pre-configured to work. A call from any phone to controller’s SIM card number will turn on the 5 OUT relay output for 3 (three) seconds. The controller can be installed without any additional configuration if such operation mode is acceptable.

1. A nano-SIM card must be inserted into the **GV17**. Turn off PIN code requests for the card before inserting it into the controller.
2. Connect a power source to the **GV17** (see 2 “Wiring schematics for the GSM gate controller **GV17**”).
3. Turn on the power for the controller. This should trigger the following **GV17** LED indications:
  - The “Power” indicator should blink green;
  - The “Network” indicator should be green solid and blink yellow.

The default settings allow control by anyone who calls the phone number of the SIM card inserted into the controller.

If you want to allow only particular people to control the controller, send an SMS command with user phone numbers, who are authorized (example SMS command: **SETU 123456 +370xxxxxxxx#Peter**). After receiving such command, **GV17** will react only to the phone numbers on the list. The controller will ignore incoming phone calls from other numbers.

**Note:** If you wish to alter the default settings or turn on other functions of the controller, refer to chapter 5 „Setting of parameters using TriadisConfig software”.

## 4 Remote control

### 4.1 Control with phone call

**Note:** The first one to call (or send an SMS to) the controller will become the system administrator and will be the only one who can administer and control the controller with SMS commands.

Call the number of the SIM card inserted into the controller. The controller automatically rejects the call and turns on the **5 OUT relay output** for 3 (three) seconds. Default settings allow anyone who calls the number of the SIM card inserted into the controller to control.

### 4.2 Control with phone keyboard

**GV17** answers and allows to control the outputs with a phone call the user is allowed to control several outputs OUT:

1. Call the controller’s SIM card number. The controller will accept the call.
2. Using the phone keyboard, dial the control command (command examples can be found in the table **DTMF control commands**).



## DTMF control commands

DTMF code	Function	Description
<b>OUTPUT*STATE#</b>	Output control	Output control command (turn on/turn off; turn on/turn off for pulse time). <b>OUTPUT</b> – number of the controlled output. <b>STATE</b> – control command: <ul style="list-style-type: none"> <li><b>0</b> – turn off output;</li> <li><b>1</b> – turn on output;</li> <li><b>2</b> – turn off output for pulse time;</li> <li><b>3</b> – turn on output for pulse time;</li> </ul> (output pulse time can be set using the <i>TrikdisConfig</i> program, in the Input/Output settings table) <b>#</b> - control command end symbol. E.g. (turn on output 5): <b>5*1#</b> E.g. (turn on input 4 for pulse time): <b>4*3#</b>
<b>#</b>	Command end symbol	If you made a mistake writing a command, dial <b>#</b> and enter the control command again.

4.3 Control using *Protegeus* Cloud

With *Protegeus* users will be able to control *GV17* remotely. They will also be able to see the system state and receive all system event messages.

1. Download and launch the *Protegeus* app or use the browser version of *Protegeus* at [www.protegeus.eu/login](http://www.protegeus.eu/login).



2. Log in with your user name and password or register and create a new account.
3. Choose **Add new system** and enter the *GV17 Unique ID (IMEI)* number found on the product or on the packaging sticker.

Add new system 🔍

---

Unique ID


Enter the IMEI code. You can find it here:  
 - on the package;  
 - on the back of the controller housing;  
 - TrikdisConfig as a Unique ID.

Next


**IMPORTANT:** When adding the *GV17* to *Protegeus*:

1. The *Protegeus service* must be turned on. Turning on the service is described in chapter 5.5 Window "IP reporting";
2. The power supply must be turned on („POWER“ LED must blink green);
3. Must be registered in to network („NETWORK“ LED must be green solid and blink yellow).


4. After adding the *GV17* to *Protegeus* choose **Control** in the newly opened window.



5. In the opened window are the PGM control buttons. In the PGM control button settings choose either **Level** or **Pulse** output operation mode.



6. After clicking on a PGM button, the **GV17** output is turned on. (Example: PGM3 – output turned off; PGM4 – output turned on, the PGM operation mode **Level** is set; PGM5 – output turned on, the PGM operation mode **Pulse** is set).




### 4.4 Adding a Widget on your phone

The gate control Widget can be placed on your phone's home screen. The **GV17** must be registered to **Protegus**. Log in to **Protegus** on your phone. Close the **Protegus** window.

Touch the screen with your finger and hold. A settings bar will appear.

1. Press **Widgets**.






Find **Protegun** in the settings bar.

2. Select **Protegun**.



3. Select **Protegun** (Switch).





## GSM gate controller GV17


4. Choose **GV17 PGM Output 5**.
5. Press **ADD WIDGET**.



6. An icon will appear on the phone's screen.



Return to the home screen. Press the icon.





A circle that shows when the PGM is turned on will appear on the screen.



7. When the **GV17** is connected to the automatic gate with gate state indication, the icon will show the state of the open/closed gates.



## 4.5 Adding users on your phone


Launch Protegus application on your phone. Log in with your username and password.

1. Press **Settings**.







2. Press **Users**.



3. Press **Add user**.




4. **Access is allowed** must be checked.
5. Enter the user's e-mail address.
6. Enter the user's phone number.
7. Check the **PGM output 5** to be controlled by the user.
8. Click **OK**.







- 9. A new user appears in the user list.
- 10. Click **Save** to update the list of users on the controller.
- 11. Click the **Return to Main Menu** button.



### 4.6 Control with SMS messages

Control the relay output OUT5 with these SMS commands:

**OUTPUT5 xxxxxx ON**

**OUTPUT5 xxxxxx OFF**

**OUTPUT5 xxxxxx PULSE=002**

- xxxxxx**                    6-symbol administrator password. (default code – 123456).
- ON**                         Turn on output.
- OFF**                        Turn off output.
- PULSE=ttt**                Turn on output for a specified time. “ttt” is pulse time in seconds.

You can control other outputs with SMS, but first they need to be turned on in **TrikdisConfig**.

#### SMS control command list

Command	Data	Description
<b>OUTPUTx</b>	<i>ON</i>	Turn on output. “x” – output number. E.g.: <b>OUTPUT5 123456 ON</b>
	<i>OFF</i>	Turn off output. “x” – output number. E.g.: <b>OUTPUT5 123456 OFF</b>
	<i>PULSE=ttt</i>	Turn on output for a period of time. “ttt” is pulse time in seconds, from 1 to 999. E.g.: <b>OUTPUT5 123456 PULSE=002</b>

### 4.7 Configuration with SMS messages

#### 1. Changing the administrator’s password

For safety reasons, change the default administrator password. Send an SMS message of this format:

**PSW 123456 xxxxxx**

- 123456**                    Default administrator password.
- xxxxxx**                    New 6-symbol administrator password.

#### 2. Allow only authorized users to control the system

You can allow only specific people to control the system. From an administrator’s phone, send SMS messages with the users’ phone numbers and names:

**SETU xxxxxx +PHONENO#NAME**

- xxxxxx**                    6-symbol administrator password.
- PHONENO**                User’s phone number.
- NAME**                      User’s name or e-mail.



Once the first number is added to the **GV17**'s user phone list, the controller will react only to phone calls from the numbers on the list. The controller will ignore calls from other numbers.

### 3. Give administrator rights to another user

You can give administrator rights to other people. They will receive system information messages and will be able to add users. Send an SMS message of this format:

**SETA xxxxxx Nox=+PHONENO#NAME**

<b>xxxxxx</b>	6-symbol administrator password.
<b>Nox</b>	x – administrator's number in the list. (If you write <b>1</b> , you will transfer your administrator rights to another user.)
<b>PHONENO</b>	User's phone number.
<b>NAME</b>	User's name or e-mail.

### SMS configuration command list

Command	Data	Description
<b>INFO</b>		Request information about the controller. The response will include: controller type, IMEI number, GSM signal strength, power voltage magnitude, software version, serial number, date and time. E.g.: <b>INFO 123456</b>
<b>ASKI</b>		Input status inquiry. E.g.: <b>ASKI 123456</b>
<b>ASKO</b>		Output status inquiry. E.g.: <b>ASKO 123456</b>
<b>SETA</b>	<i>NoX=phonenr#name</i>	Add administrator to list. Adds the phone number and name to the specified line. The number must be separated from the name with a hash (#). The number must start with "+" and the international code. E.g.: <b>SETA 123456 No3=+37061234567#John</b>
	<i>NoX=DEL</i>	Deletes phone number and name from the specified line. E.g.: <b>SETA 123456 No2=DEL</b>
<b>SETU</b>	<i>phonenr#name</i>	Add new user. Adds the phone number and name to the list. The number must be separated from the name with a hash (#). The number must start with „+“ and the international code. E.g.: <b>SETU 123456 +37061234567#Peter</b>
<b>DELU</b>	<i>phoneNo</i>	Delete user with specified phone number. E.g.: <b>DELU 123456 +37061234567</b>
	<i>name</i>	Delete user with specified name. E.g.: <b>DELU 123456 Peter</b>
<b>SETB</b>	<i>Email/phoneNo</i>	Add entry into black-list (e-mail; phone No.). Pvz.: <b>SETB 123456 VardaS@mail.lt</b> Pvz.: <b>SETB 123456 +37060123456</b>
<b>DELB</b>	<i>ALL</i>	Delete all black-list. E.g.: <b>DELB 123456 ALL</b>
	<i>Email/phoneNo</i>	Delete a particular entry from the black list (for e-mail field small and capital letters are important). E.g.: <b>DELB 123456 VardaS@mail.lt</b> E.g.: <b>DELB 123456 +37060123456</b>
<b>RESET</b>		Restart the controller. E.g.: <b>RESET 123456</b>
<b>PSW</b>	<i>New password</i>	Change password. E.g.: <b>PSW 123456 654123</b>
<b>TXTA</b>	<i>Object name</i>	Set object name. E.g.: <b>TXTA 123456 House</b>
<b>TXTE</b>	<i>N1=&lt;TEXT&gt;</i> ..... <i>N5=&lt;TEXT&gt;</i>	Set SMS text about input or output activation. N1...N5 is the number of the contact on the terminal block. E.g.: <b>TXTE 123456 N1=Alarm in the living room</b>




Command	Data	Description
<b>TXTR</b>	<i>N1=&lt;TEXT&gt;</i> ..... <i>N5=&lt;TEXT&gt;</i>	Set SMS text about input or output recovery. <i>N1...N5</i> is the number of the contact on the terminal block. E.g.: <b>TXTR 123456 N5=Relay turn off</b>
<b>SETD</b>	<i>IDx=yy</i>	Set inactivity time for input "x". "yy" is inactivity time in minutes, from 0 to 2880. When the input is activated, the controller will send a notification and will not react to any further circuit disruptions during the set inactivity time. If 0 is entered, inactivity will be turn off. E.g.: <b>SETD 123456 ID1=30</b>
<b>RESD</b>	<i>IDx</i>	Resets inactivity time for input "x", if the countdown has started. E.g.: <b>RESD 123456 ID1</b>
<b>TIME</b>	<i>YYYY/MM/DD,</i> <i>HH:mm:ss</i>	Set date and time. E.g.: <b>TIME 123456 2018/01/03,12:23:00</b>
<b>RDR</b>	<i>PhoneNR#SMStext</i>	Forwards the SMS text to the specified number. E.g.: <b>RDR 123456 +37061234567#Refill account by 10EUR</b>
<b>UUSD</b>	<i>*UUSD code#</i>	Sends UUSD code to mobile operator. Operator specified UUSD codes are for checking or refilling the SIM card's balance and for similar operations. E.g.: <b>UUSD 123456 *245#</b>
<b>CONNECT</b>	<i>Protegas=ON</i>	Connect to <i>Protegas cloud</i> . E.g.: <b>CONNECT 123456 PROTEGUS=ON</b>
	<i>Protegas=OFF</i>	Disconnect from <i>Protegas cloud</i> . E.g.: <b>CONNECT 123456 PROTEGUS=OFF</b>
	<i>APN=Internet</i>	APN name. E.g.: <b>CONNECT 123456 APN=INTERNET</b>
	<i>USER=user</i>	APN user. E.g.: <b>CONNECT 123456 USER=User</b>
	<i>PSW=password</i>	APN password. E.g.: <b>CONNECT 123456 PSW=password</b>
	<i>Code=password</i>	Change <i>Protegas Cloud</i> login password. E.g.: <b>CONNECT 123456 Code=123456</b>

## 5 Setting parameters using *TrikdisConfig* software

With *TrikdisConfig* you can change the **GV17** controller's settings (if default settings are not enough) according to the program window descriptions below.

1. Download the configuration software *TrikdisConfig* from [www.trikdis.com/lt/](http://www.trikdis.com/lt/) (enter "TrikdisConfig" in the search field) and install it.
2. Using a flat-head screwdriver, remove the **GV17**'s lid as shown below:



3. Connect the **GV17** to a computer using a USB Mini-B cable.
4. Launch the configuration software *TrikdisConfig*. The program will automatically recognize the connected device and will automatically open the **GV17** configuration window.
5. Click **Read [F4]** to see current **GV17** parameters. If prompted, enter administrator's or installer's code in the pop-up window.

**Note:** The button **Read [F4]** will make the program read and show the settings currently saved on the device.  
The button **Write [F5]** will save the settings made in the program to the device.



The button **Save [F9]** will save the settings into a configuration file. You can upload the saved settings to other devices later. This allows to quickly configure multiple devices with the same settings.

The button **Open [F8]** will allow to choose a configuration file and open saved settings.

If you want to revert to default settings, click on the **Restore** button at the bottom left of the window.

## 5.1 TrikiDisConfig status bar

After connecting the **GV17** to the **TrikiDisConfig** software, the software will show information about the connected device in the status bar:

IMEI/Unique ID: 866191036923480						
Status: Ready	Device: GV17_1210	SN:003132	BL: 1.01	FW:2.03	HW:	State USB

Name	Description
IMEI/Unique ID	The device's IMEI number
State	Operational state
Device	Device type (must show <b>GV17</b> )
SN	Device's serial number
BL	Launcher version
FW	Device's firmware version
HW	Device's hardware version
State	Type of connection with the software (with USB or remote)
Role	Access level (shown after access code is approved)

When the button **Read [F4]** is clicked, the program will read and show the settings currently saved on the **GV17**. With **TrikiDisConfig**, adjust the required settings according to the program window descriptions below.

## 5.2 "System Options" window

The screenshot shows the TrikiDisConfig 1.66.29 GV17 software interface. The main window has a menu bar with 'Program', 'Action', and 'About'. Below the menu bar are buttons for 'Read [F4]', 'Write [F5]', 'Open [F8]', 'Save [F9]', and 'Disconnect'. The 'System Options' window is open, showing various configuration fields:

- General:** Object ID (0001), Object name (GV17), Time synchronization (GSM modem), SMS time synchronization (checkbox), Administrator Code (\*\*\*\*\*), Text language (Baltic), Hang-up after (0 s).
- Periodical Test:** Test Enable (checkbox), Test period (1 day(s) 0 h), Start test at (checkbox, 13:35), Test SMS text (Periodical test), To Protegus Cloud (checkbox).
- SIM:** SIM card pin (\*\*\*\*), APN (internet), Login, Password.
- SMS ack texts:** A table with 'Answer' and 'SMS text' columns. Rows include: Command done (Command done), Wrong password (Wrong password), Wrong data (Wrong data), Wrong command (Wrong command), Greeting text (You have been added to gate controller). Force greeting message (checkbox).

At the bottom of the window, there is a status bar with the same information as in the previous section: Status: Ready, Device: GV17\_1210, SN:003132, BL: 1.01, FW:2.03, HW:, State USB.



### Settings group “General”

- **Object ID** – enter account number (4 symbol hexadecimal number, 0-9, A-F. **Do not use FFFE, FFFF Object ID.**), provided by the central monitoring station.
- **Object name** – every event will be sent with the object name.
- **Time synchronization** – choose a source for setting the time.
- **SMS time synchronization** - check the box and enter the SIM card phone number of the controller. The phone number must be with an international code.
- **Administrator Code** – with this code it is possible to change all of the parameters of the controller.
- **Text language** – SMS messages are sent with the symbols of the chosen language.
- **Hang-up after** – the controller declines the call after the specified time.

### Settings group “Periodic test”

- **Test Enable** – if the box is ticked, periodic test messages are enabled.
- **Test period** – setting of test sending time period.
- **Start test at** – setting of test start time.
- **Test SMS text** – enter the test SMS message text.
- **To Protegus Cloud** – if the box is ticked, the test message will be sent to **Protegus**.

### Settings group “SIM”

- **SIM card PIN** – enter the PIN code of the SIM card.
- **APN** – enter APN name.
- **Login** – if required, enter user name.
- **Password** – if required, enter password.


### Settings group „SMS ack texts“

The text of SMS messages that the user will receive after sending SMS commands.

- **Force greeting message** - check the box to send an SMS message to the new user, who was added by SMS or **Protegus** app, to **GV17**.

## 5.3 “IN/OUT” window

### “IN/OUT” tab




- **Terminal** – controller’s input and output terminal numbers.
- **Function** – terminal type (input, output, turned off).
- **SMS event text** – enter SMS message event text.
- **SMS restore text** – enter SMS message text for when terminal is restored.
- **Type** – specify input type (NC, NO, EOL=10kΩ).



- **Inactive** –input will be inactive for specified time after first activation. Enter 0 if you want to turn this function off.
- **Delay** - input (zone) reaction time, ms.
- **CMS** – if box is ticked, the message will be sent to CMS (Central Monitoring Station) and to **Protegeus**.
- **No rest.** – do not send restore event.
- **Pulse time** – time for which the output is turned on, when output is set as **Pulse** type.
- **Sched** – assign a schedule number for controlling the output.
- **Assign IN** – assign input (IN) to output to see the actual state of the device depending on the input’s state.
- **CID** – event Contact ID code.
- **Confirm** - specify the number of the input, when the input is triggered, control of the output (OUT) will be enabled.

### “Scheduler” tab

Outputs can be controlled automatically according to a set schedule.




- **Enable** – check the box to enable the schedule.
- **Output mode** – specify the mode of operation of the PGM output: **Level** - the output will be activated for the specified time period; **Pulse** - the output will be activated at the start and end of the schedule for the set pulse duration.
- **Holiday mode** - specify the mode of how the time schedule should work when the holidays begin (Disabled / Ignore on holidays / Additional on holidays / Only holidays).
- **Holidays** - check the box to use a holiday schedule when the schedule is the same as a holiday.
- **Start time** – specify the time and days of the week from when the output will be turned on.
- **End time** – specify the time and days of the week until when the output will be turned on.

If the PGM output mode is set to **Level** and only **End time** is specified in the **Scheduler** table, then the PGM output will be disabled at the specified time, if it was enabled. An output control schedule must be assigned to an PGM output.

### „Holidays“ tab

Enter the calendar holidays during which it will be possible to set the additional activation of the PGM output provided in the Scheduler table.



- **En.** – check the box to specify a specific holiday interval.
- **Start date** – specify the start date of the holidays.




- **Stop date** – specify the end date of the holidays.
- **Start time on holidays** – specify the start time of the holidays.
- **Stop time on holidays** - specify the end time of the holidays.

## 5.4 “Modules” window

### „Modules“ tab

If there is wireless internet (WiFi) or wired internet at the **GV17** installation site, the **W485** WiFi module or the **E485** „Ethernet“ module can be connected to the **GV17** controller. The module will be able to transfer data to **Protegeus** and CMS (central monitoring station) via the Internet. Using a module (**W485** or **E485**) with **GV17**: 1) does not use mobile internet, it is also possible to disable **GV17** GPRS data transmission; 2) You can use the **GV17** without a SIM card (controlled by the **Protegeus** apps).




- **Modules** – select the module that is connected to the gate controller via RS485 from the list.
- **Serial No.** – enter the module serial number (6 digits), which is indicated on stickers on the module’s case and packaging.

After selecting the connected module and entering its serial number, go to **Modules** → **Parameters**.

### „Parameters“ tab

#### WiFi module W485 settings window



### „Network parameters“ settings group

- **DHCP mode** – WiFi module’s mode for registering to network (manual or automatic). Check the box (automatic registration mode) and the WiFi module will automatically scan the network settings (subnet mask, gateway) and will be assigned an IP address..
- **Static IP** – static IP address for when manual registering mode is set.
- **Subnet mask** – subnet mask for when manual registering mode is set.
- **Default gateway** – gateway address for when manual registering mode is set.
- **Wifi SSID name** – name of the WiFi network that the **W485** will connect to.
- **Wifi SSID password** - WiFi network password.



## „Working mode“ settings group

- **Disable indication of the absence of a SIM card** – checking the box will disable the indication of the absence of the SIM card in the **GV17** controller.
- **Use dial and SMS when the internet module is connected** – checking the box will enable control of the gate controller via call and SMS. If the field is not checked and there is a WiFi network, then the call and SMS messages are not used. If the field is unchecked and there is no WiFi network, then **GV17** can manage call and SMS messages. **GV17** will send SMS messages to the user.
- **Disable the use of SIM card mobile data** – checking the box will disable the use of mobile data from the SIM card. Data will only be sent via module **W485**. If the WiFi network is disconnected, **GV17** will store data in memory. After restoring the WiFi network, the **GV17** will send the saved data via the WiFi **W485** module.

## „Ethernet“ module E485 settings windows



## „Network parameters“ settings group

- **DHCP mode** – „ethernet module’s mode for registering to network (manual or automatic).
- **Static IP** – static IP address for when manual registering mode is set.
- **Subnet mask** – subnet mask for when manual registering mode is set.
- **Default gateway** – gateway address for when manual registering mode is set.

## „Working group“ settings group

- **Disable indication of the absence of a SIM card** – checking the box will disable the indication of the absence of the SIM card in the **GV17** controller.
- **Use dial and SMS when the internet module is connected** – checking the box will enable control of the gate controller via call and SMS. If the field is unchecked and there is internet, then SMS and calls are not used. If the field is unchecked and there is no Internet, then **GV17** can manage call and SMS messages. **GV17** will send SMS messages to the user.
- **Disable the use of SIM card mobile data** – checking the box will disable the use of mobile data from the SIM card. Data will only be sent via module **E485**. If the internet disappears, **GV17** will store data in memory. When the Internet is restored, the **GV17** will send the saved data via the “Ethernet” **E485** module.





## 5.5 “IP Reporting” window

### Settings group “Primary channel”

- **Communication type** – choose the type of communication (IP, SMS) with the CMS (Central Monitoring Station) receiver.
- **Domain or IP** – enter the receiver’s domain or IP address.
- **Port** – enter the receiver’s network port number.
- **Phone number** – phone number of CMS receiver capable of receiving SMS messages (e.g.: 370xxxxxxx), when selected **Communication type** is SMS.
- **Encryption Key** – 6-digit message encryption key that must match the encryption key of the CMS receiver.

### Settings group “Backup channel”

The settings are identical to those of the main communication channel.

### Settings group “Settings”

- **Return to primary after** – time period after which the controller will attempt to regain connection with the primary channel.
- **IP Ping period** – enable sending of PING signal and set the length of its period.
- **SMS Ping period** – enable sending of PING signal and set the length of its period.
- **Backup reporting after** – specify amount of attempts to connect with the main channel, after which the controller will automatically connect to the backup connection channel.
- **DNS1 and DNS2** – IP addresses of DNS servers.

### Settings group “Backup channel 2”

- **Phone number** - phone number of CMS receiver capable of receiving SMS messages (e.g.: 370xxxxxxx). The backup SMS channel is used when messages fail to send with both primary and backup channels. It is extremely useful because it functions even when IP connectivity is disrupted in the mobile operator’s network. This channel works only when GPRS mode is set both for the main channel and backup channel. SMS messages will be sent to the response center’s SMS receiver: 1) as soon as the **GV17** is enabled for the first time; 2) after loss of TCP/IP or UDP/IP connection in the main and backup channels.

### Settings group “PROTEGUS cloud”

- **Enable connection** – enable **Protegeus** service, the **GV17** will be able to exchange data with the **Protegeus** app and also remote configuration with **TrikiDisConfig** will be possible.



- **Parallel reporting** – the messages are sent simultaneously to the CMS, *Protegnus* and to users. When not enabled, messages to *Protegnus* and users will be sent only after being sent to CMS.
- **Protegnus Cloud Code** – 6-digit code for connecting with *Protegnus* (default code - 123456).

## 5.6 “User list” window

### “Users” tab

ID	E-mail address	Tel number	Name	En	GRE	Sche 5	More Settings
10			Not authorized	<input type="checkbox"/>	<input type="checkbox"/>	n/a	<input checked="" type="checkbox"/> More Settings
1A	peter@trikdis.it	+37060123456	Peter	<input checked="" type="checkbox"/>	<input type="checkbox"/>	n/a	<input checked="" type="checkbox"/> More Settings
2A				<input checked="" type="checkbox"/>	<input type="checkbox"/>	n/a	<input type="checkbox"/> More Settings
3A				<input checked="" type="checkbox"/>	<input type="checkbox"/>	n/a	<input type="checkbox"/> More Settings
4A				<input checked="" type="checkbox"/>	<input type="checkbox"/>	n/a	<input type="checkbox"/> More Settings
5A				<input checked="" type="checkbox"/>	<input type="checkbox"/>	n/a	<input type="checkbox"/> More Settings
6A				<input checked="" type="checkbox"/>	<input type="checkbox"/>	n/a	<input type="checkbox"/> More Settings
7A				<input checked="" type="checkbox"/>	<input type="checkbox"/>	n/a	<input type="checkbox"/> More Settings
11	alena@trikdis.it	+37061234567	Alena	<input checked="" type="checkbox"/>	<input type="checkbox"/>	n/a	<input checked="" type="checkbox"/> More Settings

- **ID** - user serial number. Numbers with the letter "A" (1A to 7A) are administrator numbers that can make settings on the controller, control outputs, and receive messages from the gate controller. Other user numbers (11 to 999) can control outputs.
- **E-mail address** – specify administrator’s name or e-mail address.
- **Tel number** – specify administrator’s phone number (e.g.: +370xxxxxxx).
- **Name** – specify user’s name.
- **En** - check the box for the user to be activated.
- **GRE** - check the box to send an SMS message to the GV17 user.
- **Scheduler** – select the schedule number by which the user will be allowed to control the controller.
- **Output** - mark the number of the output that will be controlled by the user.
- **More settings** - by clicking on the **More settings** button, an additional user settings window will open.

**Note:** If box **En**. is unticked for user **No.10** with the name **Not authorized**, users not on the users list will be banned from controlling the controller with phone call.



## Administrator settings (numbers from 1A to 7A)

- **ID** – administrator number.
- **Enabled** – boxed is ticked, user is allowed to control outputs OUT.
- **Name** – specify administrator's name.
- **E-mail address** – specify administrator's e-mail address.
- **Phone number** – enter the administrator phone number.
- **ACK for SMS message** – administrator will get answer SMS messages when they control and configure the controller with SMS messages.
- **Receive test SMS** – check the box and administrator will receive test messages.
- **Forward unknown SMS** – SMS message forwarding from unknown numbers.
- **SMS notification for** – specify events that the administrator will receive SMS notifications about.
- **Can control output** - mark the output number that will be controlled by the administrator.

The screenshot shows the 'User settings' form for administrator ID 1A. The form includes the following fields and options:

- ID: 1A
- Enabled:
- Name: Peter
- E-mail address: peter@trikdis.it
- Phone number: +37060123456
- Keypad code: (empty)
- ACK for SMS message:
- Receive test SMS:
- Forward unknown SMS:
- SMS notification for: IN1  OUT5
- Can control outputs: OUT5

A 'Save' button is located at the bottom of the form.

## User settings (numbers from 11 to 999)

- **ID** – user number.
- **Enabled** – boxed is ticked, user is allowed to control outputs OUT.
- **Name** – specify user's name.
- **E-mail address** – specify user's e-mail address.
- **Phone number** – enter the user phone number.
- **Assign schedule** – assign a schedule (specify a schedule number) for when the user can control outputs OUT.
- **Valid from** – specify date and time from when the user can control the controller.
- **Valid until** – specify date and time until when the user can control the controller.
- **Enable counter** – check the box to enable the counter.
- **Set counter** – specify number of times that user can control the controller during the chosen time.
- **Current counter** - current number of control times.
- **Can control outputs** - mark the number of the output that will be controlled by the user.

The screenshot shows the 'User settings' form for user ID 11. The form includes the following fields and options:


- ID: 11
- Enabled:
- Name: Alena
- E-mail address: alena@trikdis.it
- Phone number: +37061234567
- Keypad code: (empty)
- Assign schedule: n/a
- Valid from:  20/11/2020 15:00:00
- Valid until:  21/11/2020 15:00:00
- Enable counter:
- Set counter: 0
- Current counter: 0
- Can control outputs: OUT5

A 'Save' button is located at the bottom of the form.




### “Scheduler” tab

The user can control the Outputs according to the set schedule. Schedule must be assigned to user.




- **Enable** – enable time schedule when the user will be able to control the controller’s outputs.
- **Start time** – specify time and days of the week from when the user can control controller’s outputs.
- **Stop time** – specify time and days of the week until when the user can control controller’s outputs.

### “Black list” tab



The **Black list** contains e-mail addresses and phone numbers of users who are banned from controlling the **GV17**. There is an easy way to add new items to the black list straight from the events log. Right-click on a telephone number or e-mail address and choose “Add to black list”.

## 5.7 “Events Log” window



Click the button **Read Log**. The **Events Log** will be read from the controller’s memory. The **Events log** provides information about the controller’s actions and its internal events.

## 5.8 Restore default settings

To restore the default settings of the **GV17** controller you need to click the **Restore** button in the **TrikiDisConfig** program window.



Default settings

**Restore**

IMEI/Unique ID:  
866191036923480

---

Status: Ready      Device: GV17\_1210      SN:003132      BL: 1.01      FW:2.03      HW:      State      USB

### 5.9 Settings for gate state indication

**Proteus** app and Widget can show the current state of the gates (closed or open). For this to work, the **GV17**'s input IN1 must be connected to the automatic gate's state output as shown in chapter 2.5 "Schematic for connecting an automatic gate opener to the GV17".

In the TrikdisConfig window "IN/OUT", assign the connected input to the **GV17** output that will control the gates:

TrikdisConfig 1.66.29 GV17

Program    Action    About

Read [F4]    Write [F5]    Open [F8]    Save [F9]    Disconnect

System Options

**IN/OUT**    Scheduler    Holidays

Input/Output settings

Termina	Function	SMS event text	SMS restore text	Type	Inactive, mir	Delay	CMS	No rest.	Pulse Time, s	Sched	Assign I	CID	Confirm
1 IN	Input	Open	Close	NO	0	400	<input type="checkbox"/>	<input type="checkbox"/>	0		N/A	130	N/A
2 IN	Disabled	IN2 event	IN2 restore	N/A	0	400	<input type="checkbox"/>	<input type="checkbox"/>	0		N/A	130	N/A
3 I/O	Disabled	I/O 3 ON	I/O 3 OFF	N/A	0	400	<input type="checkbox"/>	<input type="checkbox"/>	0		N/A	130	N/A
4 I/O	Disabled	I/O 4 ON	I/O 4 OFF	N/A	0	400	<input type="checkbox"/>	<input type="checkbox"/>	0		N/A	130	N/A
5 OUT	Output	Relay ON	Relay OFF	Pulse	0	400	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	3		1 IN	130	N/A

If you want to receive SMS messages about the gates opening/closing, enter SMS texts for input 1IN event/restore. In the "Users" window, click on the **More settings** button.

TrikdisConfig 1.66.29 GV17

Program    Action    About

Read [F4]    Write [F5]    Open [F8]    Save [F9]    Disconnect

System Options

IN/OUT

Modules

IP Reporting

**User list**

Events Log

Firmware

Users    Scheduler    Black list

Clear users    Out

ID	E-mail address	Tel number	Name	En	GRE	Sche	5	More Settings
10			Not authorized	<input type="checkbox"/>	<input type="checkbox"/>	n/a	<input checked="" type="checkbox"/>	More Settings
1A	peter@trikdis.it	+37060123456	Peter	<input checked="" type="checkbox"/>	<input type="checkbox"/>	n/a	<input checked="" type="checkbox"/>	More Settings
2A				<input checked="" type="checkbox"/>	<input type="checkbox"/>	n/a	<input type="checkbox"/>	More Settings
3A				<input checked="" type="checkbox"/>	<input type="checkbox"/>	n/a	<input type="checkbox"/>	More Settings

In the "User list" window, tick the IN1 box if you want the user to receive SMS messages about the state of the gate. Click **Save**.

User settings

ID      1A

Enabled     

Name      Peter

E-mail address      peter@trikdis.it

Phone number      +37060123456

Keypad code     

ACK for SMS message     

Receive test SMS     

Forward unknown SMS     

SMS notification for      IN1     OUT5

Can control outputs      OUT5

**Save**




## 6 Setting parameters remotely

**IMPORTANT:** Remote configuration will only work when:

1. **Proteus service** is enabled. Enabling the service is described in chapter 5.5 "IP reporting" window;
2. Power is on („POWER“ LED is blinking green);
3. Connected to network („NETWORK“ LED is green solid and yellow blinking).

1. Download the program **TrikdisConfig** from [www.trikdis.com](http://www.trikdis.com).
2. Make sure that the **GV17** controller is connected to the internet and connection to **Proteus** is enabled.
3. Launch the configuration program **TrikdisConfig** and in the field **Unique ID** of the *Remote access* section enter the IMEI number of your **GV17** (the IMEI number is given on the stickers that can be found on the lower part of the device's case and on the packaging).



4. In the field **System Name** you can give any name to this **GV17**. Click **Configure**.
5. The controller configuration window will open. Click the button **Read [F4]** for the program to read the parameters currently set for the **GV17**. If a window for entering the *Administrator code* opens, enter the six-symbol *administrator code*. To make the program remember the code, tick the box next to **Remember password** and click the button **Write [F5]**.
6. Set the desired settings for the **GV17** and afterwards click **Write [F5]**. To disconnect from the **GV17** click **Disconnect** and exit the **TrikdisConfig** program.

## 7 Testing of GSM gate controller GV17

When configuration and installation are finished, test the system:

1. Check if the power is on;
2. Check network connectivity (**NETWORK** indicator must be green solid and blink yellow);
3. To test the **GV17**'s inputs, trigger them and make sure that the recipients get correct messages;
4. To test the **GV17**'s outputs, turn them on remotely and make sure that the recipients get correct messages and the outputs are activated correctly.


## 8 Updating firmware manually

**Note:** When the **GV17** is connected to **TrikdisConfig**, the program will offer to update the device's firmware if updates are available. Updates require an internet connection.

If antivirus software is installed in your computer, it might block the automatic firmware update function. In this case you will have to reconfigure your antivirus software.

The **GV17**'s firmware can also be updated and changed manually. All prior **GV17** parameters remain after update. When writing manually, the firmware can be changed to an older or a newer version. Follow these steps:

1. Launch **TrikdisConfig**.
2. Connect the **GV17** to a computer using a USB Mini-B cable or connect to the **GV17** remotely. If a newer version of firmware is available, the program will offer to install it.
3. Choose the menu branch **Firmware**.
4. Click the **Open firmware** button and choose the required firmware file. If you do not have the file, the newest version of the firmware file can be downloaded by registered users from [www.trikdis.com](http://www.trikdis.com), under the download section of the **GV17**.



5. Click the button **Start update [F12]**.
6. Wait for the update to finish.